

Hilka

83959520

30875

2 Ton Tow Bar With Spring Damper



INSTRUCTIONS

SPECIFICATION

Maximum rated load..... 2000kg
Maximum distance between hooks..... 1800mm


SAFETY

1. Ensure the towing eye on each vehicle is located at approximately the same height above the ground.
2. The part of the vehicle to which the towing brace is attached must be robust. For concise and detailed information on where to attach this tool refer to the vehicle manufacturer's service manual.
3. When towing ensure that the steering lock is released, and your hazard warning lights are on.
4. The towing brace must be kept straight whilst towing. Depending on the relative position of the towing eyes it may be necessary for the vehicles to be offset to one side.
5. Never tow a vehicle with defective brakes.
6. Do not exceed a speed limit of 30mph., even on a clear road.
7. Care must be taken when starting and stopping. The towing bar and eyes will not be capable of withstanding the forces of emergency braking.
8. Although this is a fixed length towing brace the vehicle being towed must operate the brakes for both vehicles as when using a basic tow rope.

OPERATION


1. Assemble the three parts of the towing brace and secure into place using the locking pins and safety clips. Ensure that both hooks are pointing in the same direction. (i.e. both hooks pointing upwards).
2. Open the hook gate, place the hook through the towing eye. (fig. 1 (b)).
3. The hook gate can now be firmly adjusted against the towing eye, and secured in place using the locking pin and safety clip. This should ensure jolt-free towing.

Fig. 1 (a)



INCORRECT

Fig. 1 (b)



CORRECT